

VALVE TIMING INFORMATION

Engine: Porsche 912

Grind #: 86-5

| | | <i>Intake</i> | <i>Exhaust</i> | | |
|-------------------|-----|----------------------|-----------------------|-----|------------|
| Valve Lash: | | .006 | .006 | | |
| Valve Lift: | | .420 | .358 | | |
| Duration: | | 280° | 280° | | |
| Duration @ .050 : | | 244° | 244° | | |
| Lobe Center: | | 108° | 108° | | |
| Intake Opens | 14° | Before TDC | Exhaust Opens | 50° | Before BDC |
| Intake Closes | 50° | After BDC | Exhaust Closes | 14° | After TDC |

**Valve Timing Is Checked With Zero Valve Lash
@ .050 Inches Of Valve Lift.**